

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11

P/N 72120 Glue-On Mirror Mount



Mount should be applied in temperatures between 50° to 70° and not in direct sunlight.

Directions for use

1. Find and mark location to mount mirror base. Insure that once mounted the location will allow proper view and adjustment for mirror. Mark location with a felt tip pen on the OUTSIDE of windshield.
2. Thoroughly clean inside of windshield first with a razorblade removing any prior adhesive or contaminants. Finish by cleaning area with an alcohol pad (not supplied) or clean cloth saturated with alcohol; also clean the back of the mirror mount.
DO NOT USE THE BLUE CLEANER – ACTIVATOR, DO NOT TOUCH CLEANED AREAS.
3. Follow by peeling away the corners of the Blue Cleaner – Activator packaging to expose the towelette completely without removing it from the package. Clean the marked area with the towelette in a circular motion, overlapping the marked area by at least a ½ inch. Allow to dry at least two minutes.
DO NOT TOUCH THE WINDSHIELD AFTER CLEANER – ACTIVATOR APPLICATION.
4. Next open Yellow adhesive package and apply One Drop of adhesive to the center of the mirror mount. Immediately apply the mount to the windshield and hold firmly for 1-2 minutes.

Allow to set at least 30-45 minutes before mounting mirror to windshield.

9-11