



Remote Power Steering Reservoir For Hydroboost Systems

#77810 / #BLK77810

Carefully install bracket onto reservoir body at least 2.5" as shown. Mock up reservoir for position and mark. Use template to drill 1 1/32" holes for the bracket. (If you are replacing a Billet Specialties reservoir, the holes are the same.) See diagram below for line routing. Fill reservoir to marked lines and bleed system per the Hydroboost System.

